


# DOUBLETRACKER

## Stereo

### CONNECTIONS



© 2025 Jack Deville LTD.

### --QUICK START GUIDE--

#### Connection Schemes:

Mono-In / Mono-Out - connect to:

Primary Input & Primary Output

Mono-In / Stereo-Out - connect to:

Primary Input & Both Outputs

True-Stereo In / True-Stereo Out - connect to:

Both Inputs, & Both Outputs

#### SYNC/COMP Mode:

Press SYNC/COMP button to select

SYNC Mode (Red LEDs):

doubled track matched in pitch

COMP Mode (Green LEDs):

doubled track complimentary pitch

#### Preset Usage:

Set controls to desired setting and press SAVE button.

Preset LED will blink and the setting can be recalled at any time by pressing the PRESET footswitch.

#### Expression Pedal Usage:

Connect TRS expression pedal to EXP. jack, and rotate control to be assigned to expression pedal to full CW rotation (EXP marker).

Expression Pedal Wiring Connections:

-Tip: Wiper

-Ring: High

-Sleeve: Ground

#### Tech Specs:

Input Impedance:

Output Impedance:

Current Draw:

~495K $\Omega$  (each channel)

~2K $\Omega$  (each channel)

~73mA @ 9VDC